


Gooch & Housego

Optical Fibre Capabilities

Dr Andrew Robertson – Senior Vice President





Presentation Contents

- Manufacturing Capability
 - Passive components
 - Active components
 - Additional Fiber Laser Components
- Sub-assembly capability
 - Optical Sub-assemblies

Fibre Optic Facility Basics

- UK Factory
 - -27,000 sq ft
 - ISO 9001
 - 115 employees
 - Submarine qualified



- Czech Republic
 - Contract Manufacturing
 - ISO 9001
 - 45 fused operators
 - Submarine qualified



Fused Components


SM Components

- Tap couplers and wavelength combiners
- Polarization Maintaining
- Visible to 2um
- Fibre laser tap monitor and pilot beam delivery


MM components

- Power Combiners
- Signal feedthrough amplifier components
- LMA taps

Fused Biconic Taper Technology




Fusion Process




Very accurate control of process and heating profile required for uniform low loss taper and optimum device performance


Tapered Fibre Bundles




7x1 MM Combiner



- Data from 260 devices (1820 ports)
- Average port Tr = 94%
- Average combiner Tr = 94%
- Reliability Test program
 - 50,000 device hours under full operating conditions




Tapered Fibre Bundles – power handling comments



- Negligible power lost in down taper
- Small power lost in splice
- Most light lost where buffer begins
 - Light of higher NA cannot be captured
 - Buffer strips out light & generates heat
 - Thermal management required


Power Limits – MM Combiner


- Power combiner designs can be optimized for 1kW+ long term use.
 - Cooling helps
- Alternative design requires different buffer can also be used
 - Polyimide, silicone
- Housing design for high power transmission
 - Improved thermal transmission
 - Heat removal




Level 3, kW class housing

Additional MM components
















PM 6+1x1

Fused Component Manufacturing










Screening, Measurement, QA












Measurements Database

- All measurements logged and saved on central database
 - With serial number of component, measurement data can be recalled immediately
 - 10 years worth of components!







Active Fibre Optics



High reliability active components

- Laser welded technology
- Proprietary patented advanced glass solder materials
- Market leader in emerging Avionic & Defence 'actives' photonics
- This example shows a transceiver for 'towed decoy'applications
















Multi-element optical design









Soldered Designs




Rugged Spalce Qual, Designs




TOSA / ROSA Designs




Exotic Material Designs



Fiber Coupled & Free Space



High Power Designs



Optical Subsystem Designs



Cleanroom packaging facilities






Photonic Packaging Design Capability

- Specialist designers of optoelectronic packaging
 - In-house skill set
 - Custom design
 - Active devices
 - Optical
 - Mechanical



- Design for manufacture
- Thermal management
- Hermetic design
- Fibre handling





Wide Product capability

- Fibre pigtailed, recepticalized & free space sources
 - Lasers & LEDs
 - SLEDs & SOAs
 - DFB, FP & VSELs
- Fibre pigtailed & recepticalized detectors
 - APDs & PIN diodes
 - Arrays

Actives & Passives Reliability

- Regular Telcordia qualification
 - Actives & Passives
 - All facilities
- Harsh Environment testing
 - Military, avionic & space requirements
- Customer specific testing programmes
 - Sub-marine cable customers
 - Avionic gyroscope customers
 - Satellite customers
 - Military customers
- High Power Test Program
 - MM fibre laser components
 - SM fibre laser components

Advanced Fibre Laser Components

Fibre coupled AOM


Hermetic version for sensor and space applications


Non-hermetic version

Targeting price sensitive fibre laser market

Fibre-Q performance


- Data from 440 devices
- 80MHz, 1060nm, 35ns rise time
- Specification
 Specification Insertion Loss < 3dB
 Extinction ratio > 50dB






Fibre-Q summary

- > Hermetic and non hermetic version
- > 1060nm & 1550nm
 - > 2um in development
- > 1W and 5W version
- ➤ 1500+ shipped
- > Space qualified version




- ➤ Up to 5W CW power
- ➤ Typical 75% transmission fibre to fibre

Fibre coupled isolator




High power Isolator 30 -100W

20W Isolator Design




High Power Isolator Performance




- Measured Data
- > Isolation = 35dB
- ➤ Insertion Loss ~ 0.4dB
- > Return Loss > 50dB

Integrated Optical Modules


- Full design or "build to print" to meet footprint, fibre routing, components, PCBs
- Complete supply chain management of core technologies
- Extensive knowledge of passive & active components, power supplies, computer interface, motion control, thermal management
- Assembly technicians skilled in handling, routing and splicing all types of fibres & components





Optical Integrated Modules

OEM sub-assembly




Turnkey systems








Modules Facility










Fibre Handling Knowledge

Constant module throughput

- Sensor, Telecoms, Biomedical
- 10-100 per week
- Varying complexity
- Leverage full G&H optics capabilities
- Manufacturing capability in UK, CZ, and North America





Summary

- Comprehensive active and passive fibre product range
- Emphasis on high specification and high reliability
- Mature manufacturing capability with proven cost reduction roadmap
- High quality sub-assembly facility
- G&H Advanced Product Development

Additional Information





_{光技術をサポートする} 株式会社オプトサイエンス

http://www.optoscience.com

東京本社〒160-0014 東京都新宿区内藤町1番地 内藤町ビルディング TEL:03(3356)1064 FAX:03(3356)3466 E-mail:info@optoscience.com 大阪支店〒532-0011 大阪市淀川区西中島7-7-2 新大阪ビル西館 TEL:06(6305)2064 FAX:06(6305)1030 E-mail:osk@optoscience.com 名古屋営業所〒450-0002 名古屋市中村区名駅2-37-21 東海ソフトビル

TEL:052(569)6064 FAX:052(569)8064 E-mail:ngo@optoscience.com